


W24SIREN-wiring for WGAP864 panel

Jumpers
Tone: 1 or 2
Sound: Lo or Hi



Connect to O/P 3 of WGAP864 panel to show Arm/Disarm status