

Solar Panel Control Box LED Explanation Table

No.	Status	Yellow LED (Operating LED)	Green LED (Charging LED)	Red LED (Discharging LED)
1	Initialize	Flashing	Flashing	Flashing
2	Charging	ON	ON	Off
3	Normal Operation	ON	Off	ON
4	Standby	ON	Off	Off
5	Invalid Parameter	Slow flash	Slow flash	Off
6	LED Light issue	Off	Off	Quick flash
7	Battery Reversed	Off	Quick flash	Off
8	Battery Low	Off	Slow flash	Off
9	Driving time expired	Off	Off	Slow flash
10	Battery Voltage Over Voltage	Slow flash	Off	Off
11	PV Over Voltage	Quick flash	Off	Off
12	PV Reversed	Quick flash	Quick flash	Off