



Reolink Solar Panel Quick Start Guide

Technical Support

For more troubleshooting, please go to FAQs on our website:
<https://reolink.com/faqs/>

For other technical support, please contact us at
support@reolink.com

QG1_A

What's in the Box



Solar Panel
x1




Bracket
x1




Screws
(in pack)

Welcome to Reolink
Easy Setup Within Minutes!

1.




Please select a position with the most sunlight throughout the year for your solar panel. The Reolink solar panel only needs a few hours of direct sunlight to sufficiently power your camera daily. The amount of energy that the solar panel can produce is affected by weather conditions, seasonal changes, geographic locations, etc.




2.

Mount the bracket with the mounting template and the screws provided in the package.




3.

Slot the solar panel into the bracket and make sure it's secure.



4.

Loosen the adjusting control on the bracket and adjust the angle of the solar panel to make it receive direct sunlight, and then retighten the adjusting control to secure your setting.



5.

Connect the solar panel to the Reolink Argus 2 camera with the micro USB cable.

Important Notes:

1. Make sure that there is NO blocking on the solar panel. The energy harvesting efficiency drops drastically even when a small portion of the solar panel is blocked.
2. Please don't install the solar panel completely horizontally. Otherwise your solar panel might accumulate dust and other debris easily. It's advised to install the solar panel angularly to make it receive direct sunlight.
3. Wipe the solar panel regularly to remove the dust or debris.

