

### Package includes:


- 1 x 4.3 inch LCD display
- 1 x Set of installation cables
- 1 x Installation manual



Resolution	480x234
Aspect ratio	16:9
Channels	2
Split screen	No
Power supply	12VDC
Remote control	No

### Disconnect the battery prior to doing electrical work on the vehicle.

1. Connect the monitor's power wire (red) to a 12v positive power supply on the vehicle. Some constant 12v power sources include the vehicle's alarm system and clock.
2. Connect the monitor's ground wire (black) to a suitable ground point.
3. Connect the camera's video cable(s) to the monitor's video cables(s).
4. The monitor and camera(s) can be set up in three different ways:
  - a. **One camera that always displays on the monitor**  
Connect the camera's red wire to any constant 12v power supply.
  - b. **One camera that only displays while the vehicle is reversing**  
Connect the camera's red wire to the 12v power supply behind the reverse light.
  - c. **Two cameras; one that displays by default, another that replaces it while the vehicle is reversing**  
Connect one camera's red wire to any constant 12v power supply, and the second (reverse) camera's red wire to the 12v power supply behind the reverse light.
5. Connect the camera's ground wire (black) to a suitable ground point.



### Test the reverse camera auto-activation:

1. Engage the park brake and turn the ignition key on, without starting the vehicle.
2. Select the reverse gear with the gear shift. If wired correctly, the monitor should automatically display the reverse camera's feed.

### Camera/monitor position example:

- A: Monitor position (Dashboard)
- B: Camera position (Rear camera)
- C: Camera trigger (Connect to the switch side of reverse light)

